# *9918DP / 3218*

Operating Instructions

# *COPY REFERENCE*



S1144

### Introduction

This manual contains detailed instructions on the operation and maintenance of this machine. To get maximum versatility from this machine all operators should carefully read and follow the instructions in this manual. Please keep this manual in a handy place near the machine.

Please read the Safety Information before using this machine. It contains important information related to USER SAFETY and PREVENTING EQUIPMENT PROBLEMS.

### Notes:

Some illustrations may be slightly different from your machine.

Certain options may not be available in some countries. For details, please contact your local dealer.

### Operator Safety:

This machine is considered a CDRH class I laser device, safe for office/ EDP use. The machine contains a 5-milliwat, 760 - 800 nanometer wavelength, GaAlAs laser diode. Direct (or indirect reflected) eye contact with the laser beam might cause serious eye damage. Safety precautions and interlock mechanisms have been designed to prevent any possible laser beam exposure to the operator.

### Laser Safety:

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical unit in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement or the optical subsystem is required.

### Warning:

Use of controls or adjustment or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.

### Notes:

Two kinds of size notation are employed in this manual. With this machine refer to the Inch version.

For good copy quality, Ricoh recommends that you use genuine Ricoh toner.

Ricoh shall not be responsible for any damage or expense that might result from the use of parts other than genuine Ricoh parts in your Ricoh office product.

### Power Source:

120V, 60Hz, 10A or more

Please be sure to connect the power cord to a power source as above. For details about power source, see ⇒ P.87 *"Power Connection"*.

**USA (This information is for facsimile option users only.)**

## ❖ FCC Requirements

1. This equipment complies with Part 68 of the FCC rules. On the cover of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company.
2. This equipment uses the following USOC jack: RJ11C
3. The REN is used to determine the quantity of devices which may be connected to the telephone line. Excessive REN's on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of the REN's should not exceed five (5.0). Contact the telephone company to determine the maximum REN for the calling area.
4. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
5. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications in order to maintain uninterrupted service.
6. In the event of operation problems (document jam, copy jam, communication error indication), refer to the solving problems section in this manual.
7. If you cannot correct the problem, please contact the RICOH CORP. CUSTOMER SUPPORT DEPT. at 1-800-FASTFIX for repair and warranty information. If it is causing harm to the telephone network, the telephone company may request you to disconnect the equipment from the network until the problem is resolved.
8. This equipment cannot be used on telephone company-provided coin service. Connection to Party Line Service is subject to state tariffs.

## ❖ WHEN PROGRAMMING EMERGENCY NUMBERS AND/OR MAKING TEST CALLS TO EMERGENCY NUMBERS:

1. Remain on the line and briefly explain to the dispatcher the reason for the call before hanging up.
2. Perform such activities in the off-peak hours, such as early morning hours or late evenings.

**CANADA (This information is for facsimile option users only.)**

The Industry Canada label identifies certified equipment. This certification means that the equipment meets telecommunications network protective, operational, and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

In accordance with IEC 60417, this machine uses the following symbols for the main power switch:

**| means POWER ON.**

**⏻ means STAND BY.**

Copyright © 1999 Ricoh Co., Ltd.

# Safety Information

When using your machine, the following safety precautions should be always followed.

## Safety During Operation

In this manual, the following important symbols are used:

> ⚠ ***WARNING:***
> ***Ignoring this warning could cause serious injury or even death.***
>
> ⚠ ***CAUTION:***
> *Ignoring this caution could cause injury or damage to property.*

## Examples Of Indications

Symbols ⚠ mean a situation that requires you take care.

Symbols ⚠ mean "Hot surface".

Do NOT carry out the operation represented by this symbol ⃠.
This example means "Do not take apart".

Symbols ● mean you MUST perform this operation.
This example means "You must remove the wall plug".

## ⚠ *WARNING:*

- *Only connect the machine to the power source described on the inside front cover of this manual.*
- *Avoid multi-wiring.*
- *Do not damage, break or make any modifications to the power cord. Do not place heavy objects on it, pull it hard or bend it more than necessary. These actions could cause an electric shock or fire.*
- *Do not plug or unplug the power cord with your hands wet. Otherwise, an electric shock might occur.*

- *Make sure the wall outlet is near the machine and freely accessible so that in event of an emergency it can be unplugged easily.*

- *Do not remove any covers or screws other than those specified in this manual. Some parts of the machine are at a high voltage and could give you an electric shock. Also, if the machine has laser systems, direct (or indirect) reflected eye contact with the laser beam may cause serious eye damage. When the machine needs to be checked, adjusted, or repaired, contact your service representative.*
- *Do not take apart or attempt any modifications to this machine. There is a risk of fire, electric shock, explosion or loss of sight. If the machine has laser systems, there is a risk of serious eye damage.*

- *If the machine looks damaged or breaks down, smoke is coming out, there is a strange smell or anything looks unusual, immediately turn off the operation and main power switches then unplug the power cord from the wall. Do not continue using the machine in this condition. Contact your service representative.*
- *If metal, liquid or foreign matter falls into the machine, turn off the operation and main power switches, and unplug the main power cord. Contact your service representative. Do not keep using the machine with a fault or defect.*

- *Do not put any metal objects or containers holding water (e.g. vases, flowerpots, glasses) on the machine. If the contents fall inside the machine, a fire or electric shock could occur.*

- ***Do not incinerate used toner or toner containers. Toner dust might ignite when exposed to an open flame. Dispose of the used toner containers according to local regulations for plastics.***

## ⚠ CAUTION:

- *Keep the machine away from humidity and dust. A fire or an electric shock might occur.*
- *Do not place the machine on an unstable or tilted surface. If it topples over, it could cause injury.*

- *After you move the machine, fix it with the caster fixture. Otherwise, the machine might move or come down to cause a personal injury.*

- *Before moving the machine, be sure to pull all four handles fully out. Not doing this may result in an injury, such as getting your fingers pinched. After moving the machine, return the four handles to their original positions.*
- *When the optional paper tray unit is installed, do not push the upper part of the main unit horizontally. If the paper tray unit becomes detached from the main unit, this could cause an injury.*

- *When you move the machine, unplug the power cord from the wall outlet to avoid fire or electric shock.*
- *When the machine will not be used for a long time, unplug the power cord.*



- *When you pull out the plug from the socket, grip the plug to avoid damaging the cord and causing fire or electric shock.*

- *If you use the machine in a confined space, make sure there is a continuous air turnover.*

- *Do not reuse stapled paper. Do not use aluminum foil, carbon-containing paper or other conductive paper. Otherwise, a fire might occur.*

- *When removing misfed paper, do not touch the fusing section because it could be very hot.*

- *This machine has been tested for safety using this supplier's parts and consumables. We recommend you only use these specified supplies.*

- *Do not eat or swallow toner.*
- *Keep toner (used or unused) and toner containers out of reach of children.*

- *This equipment is only to be installed by a qualified service personnel.*

- *Deliver to collection point for waste products. Do not be disposed of via domestic refuse collection.*

# ENERGY STAR Program

ENERGY STAR®



As an ENERGY STAR Partner, we have determined that this machine model meets the ENERGY STAR Guidelines for energy efficiency.

The ENERGY STAR Guidelines intend to establish an international energy-saving system for developing and introducing energy-efficient office equipment to deal with environmental issues, such as global warming.
When a product meets the ENERGY STAR Guidelines for energy efficiency, the Partner shall place the ENERGY STAR logo onto the machine model.
This product was designed to reduce the environmental impact associated with office equipment by means of energy-saving features, such as Low-power mode

- Low-power Mode

This product automatically lowers its power consumption 15 minutes after the last copying or printing. To exit Low-power mode, press the **[Energy Saver]** key.
For how to change the default interval before entering Low-power mode, see"Energy Saver Timer"of the"System Settings".

- Sleep Mode (Machines with fax or printer option.)

This product automatically lowers its power consumption 15 minutes after the last copying or printing even further. Printing a received fax and printing are available in this mode, but If you use the copier, press the operation switch.
For how to change the default interval before entering Sleep mode, see"Auto Off Timer"of the "System Settings".

- Auto Off Mode (Machines with copier feature only.)

To conserve energy, this copier automatically turns off 30 minutes after the last copying job has been completed. To exit the Auto Off Mode, turn on the main switch. For how to change the default interval before entering Auto Off mode, see"Auto Off Timer"of the "System Settings".

## Specification

<table>
<tr><td rowspan="2"></td><td rowspan="2"></td><td colspan="2">Copier only</td><td colspan="2">Fax or Printer is installed.</td></tr>
<tr><td>Level 1</td><td>Level 2</td><td>Level 1</td><td>Level 2</td></tr>
<tr><td rowspan="3">Low-power Mode</td><td>Power consumption</td><td>about 60W</td><td>about 30W</td><td>about 74W</td><td>about 50W</td></tr>
<tr><td>Default interval</td><td colspan="4">15min.</td></tr>
<tr><td>Recovery time</td><td>10 sec.</td><td>20 sec.</td><td>10 sec.</td><td>20 sec.</td></tr>
<tr><td rowspan="2">Sleep Mode*1</td><td>Power consumption</td><td colspan="2" rowspan="2">Not Available</td><td colspan="2">less than 36W *3</td></tr>
<tr><td>Default interval</td><td colspan="2">30 min.</td></tr>
<tr><td rowspan="2">Auto Off Mode*2</td><td>Power consumption</td><td colspan="2">0W*3</td><td colspan="2" rowspan="2">Not Available</td></tr>
<tr><td>Default interval</td><td colspan="2">30 min.</td></tr>
</table>

*1 Fax or Printer function in addition to standard Copier function.
*2 Only for Copier function.
*3 Based on Energy Star measurements.

## Recycled paper

Please contact your sales or service representative for recommended recycled paper types that may be used in this machine.

# How to Read this Manual

## Symbols

In this manual, the following symbols are used:

⚠ ***WARNING:***
This symbol indicates a potentially hazardous situation that might result in death or serious injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are described in the Safety Information section.

⚠ ***CAUTION:***
This symbol indicates a potentially hazardous situation that might result in minor or moderate injury or property damage that does not involve personal injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are described in the Safety Information section.

* The statements above are notes for your safety.

**Important**
If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

**Preparation**
This symbol indicates the prior knowledge or preparations required before operating.

**Note**
This symbol indicates precautions for operation, or actions to take after misoperation.

**Limitation**
This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

**Reference**
This symbol indicates a reference.

[ ]
Keys that appear on the machine's panel display.

[ ]
Keys built into the machine's operation panel.

# What You Can Do with this Machine (Copy Mode)



# TABLE OF CONTENTS

**Guide to Components** ..... 1
**Options** ..... 3
**Operation Panel** ..... 4
**Panel Display** ..... 6
Displays and Key Operations ..... 6

## 1. Basics

**Starting the Machine** ..... 9
When the Machine Only with Copy Feature ..... 9
When the Machine with Fax or Printer Option ..... 10
**Changing Modes** ..... 13
**Originals** ..... 14
Sizes and Weights of Recommended Originals ..... 14
Sizes Difficult to Detect ..... 15
Original Sizes and Scanning Area/Missing Image Area ..... 16
**Copy Paper** ..... 17
Recommended Paper Sizes and Types ..... 17
Envelopes ..... 20
Non-recommended Paper ..... 21
Paper Storage ..... 22
**Toner Cartridge** ..... 23
Handling Toner ..... 23
Toner Storage ..... 23

## 2. Copying

**Basic Procedure** ..... 25
**Setting Originals** ..... 27
Setting Originals on the Exposure Glass ..... 27
Setting Originals in the Document Feeder ..... 28
Setting Originals When Auto Pager Select Cannot Recoqnize the Size ..... 29
**Basic Functions** ..... 31
Adjusting Copy Image Density ..... 31
Selecting Original Type Setting ..... 32
Selecting Copy Paper ..... 33
Auto Reduce/Enlarge—Having the Machine Choose the Reproduction Ratios ... 34
**Sort** ..... 37
**Copying from the Bypass Tray** ..... 39
When Copying onto Envelopes ..... 43

**Program—Storing Your Copy Settings in Memory** ..... **47**
Storing Your Settings ..... 47
Deleting a Program ..... 48
Recalling a Program ..... 48
**Other Functions** ..... **49**
Energy Saver Mode—Saving Energy ..... 49
Interrupt—Temporarily Stopping One Job to Copy Something Else ..... 49
User Codes ..... 49
Auto Start—Entering Copy Job Settings During the Warm-up Period ..... 50
Original Tone ..... 50
**Preset Reduce/Enlarge—Reducing and Enlarging Using Preset Ratios** ..... **51**
**Zoom—Reducing and Enlarging in 1% Steps** ..... **53**
**Combine—Combining Originals into One Copy** ..... **54**
**Series Copies—Making Two-sheets Copies from Book Originals** ..... **57**
**Combination Chart** ..... **59**

## 3. What to do If Something Goes Wrong

**If Your Machine does not Operate as You Want** ..... **61**
Message ..... 61
Display ..... 62
**If You Cannot Make Clear Copies** ..... **63**
**If You Cannot Make Copies as You Want** ..... **65**
**Loading Paper** ..... **66**
**Replacing the Toner Cartridge** ..... **67**
**Clearing Misfeeds** ..... **70**
**Changing the Paper Size** ..... **72**

## 4. User Tools (Copy Features)

**Accessing the User Tools (Copy Features)** ..... **75**
Exiting from User Tools ..... 76
**User Tools Menu (Copy Features)** ..... **77**
**Settings You Can Change with the User Tools** ..... **78**
1. General Features $^{1}/_{4}$ ..... 78
1. General Features $^{2}/_{4}$ ..... 79
1. General Features $^{3}/_{4}$ ..... 80
1. General Features $^{4}/_{4}$ ..... 81
2. Input/Output ..... 82

## 5. Remarks

**Do's and Don'ts** ..... **85**

**Where to Put Your Machine** ..... **86**

Machine Environment ..... 86
Power Connection ..... 87
Access to Machine ..... 88

**Maintaining Your Machine** ..... **89**

Cleaning the Exposure Glass ..... 89
Cleaning the Platen Cover ..... 89
Cleaning the Document Feeder ..... 89

## 6. Specification

**Mainframe** ..... **91**

**Document Feeder (Option)** ..... **94**

**500 – Sheet Tray Unit (Option)** ..... **95**

**1000 – Sheet Tray Unit (Option)** ..... **96**

**Internal Tray 2 (1bin tray) (Option)** ..... **97**

**48MB Copier Memory Unit (Option)** ..... **98**

**INDEX** ..... **99**

# Guide to Components




**1. Platen cover (option) or Document Feeder (ADF) (option)**
Lower the platen cover over originals placed on the exposure glass for copying. If you have the document feeder, insert a stack of originals here. They will be fed automatically.
(The illustration shows the document feeder.)

**2. Exposure glass**
Position originals here face down for copying. See ⇒ P.14 *"Originals"*.

**3. Internal tray**
Copied paper is delivered here face down.

**4. Main power switch**
The Machine with copy feature only:
Turn on this switch to activate the machine. Turn off this switch to shut off.
The Machine with fax or printer option:
Do not touch this switch. This switch is used only by a service representative when the optional fax unit is installed.

**Note**

❒ If the machine does not operate after turning on the operation switch, check if the main power switch is turned on. If it is off, turn it on.

**5. Operation switch**
The Machine with fax or priner option:
Press this switch to turn the power on (the **On** indicator lights up). To turn the power off, press this switch again (the **On** indicator goes off).

**6. Operation panel**
See ⇒ P.4 *"Operation Panel"*.

**7. Internal tray 2 (option)**
You can specify a tray to which documents are delivered for each mode (copy, facsimile, and printer.)

**8. Paper tray (Tray 1)**
Set paper here. See ⇒ P.66 *"Loading Paper"*.

**9. Paper tray unit (Tray 2, 3) (option)**




THYH030E

### *1.* Bypass tray
Use to copy onto OHP transparencies, adhesive labels, translucent paper, post cards, envelopes and non-standard size paper. See ⇒ P.39 *"Copying from the Bypass Tray"*.

### *2.* Side cover
Open to remove jammed paper fed from the paper tray, or to replace the toner cartridge.

### *3.* Paper tray side cover
Open this cover to remove jammed paper which fed from the paper tray unit.

### *4.* Optional paper tray side cover
Open this cover to remove jammed paper which fed from the optional paper tray unit.




THYH020E

### *1.* Ventilation hole
Prevents overheating. Do not obstruct the ventilation hole by placing or leaning an object near it. If the machine overheats, a fault might occur.

# Options




THYH070E

### 1. Internal tray 2 (1 bin tray)

If you selected this as the output tray, copied paper is delivered here face down. See "14. Output Tray Prio." in the "System Settings".

### 2. Platen cover

Lower this cover over originals for copying.

### 3. Document feeder (ADF)

Insert a stack of originals here.
They will be fed automatically.

### 4. Paper tray unit

Consists of two paper trays.

### 5. Paper tray unit

Consist of one paper tray.
Other options:

- 48MB copier memory unit

# Operation Panel




### 1. [User Tools/Counter] key

- User Tools
  Press to change the default settings and conditions to meet your requirements.
- Counter
  Press to check or print the total number of copies made.
  See ⇒ P.75 *"User Tools (Copy Features)"*.

### 2. Operation panel for facsimile mode (for machine with optional fax function)

See the "Facsimile Reference".

### 3. Indicators

These indicators show errors or the status of the machine.

See ⇒ P.61 *"What to do If Something Goes Wrong"*.

### 4. Panel display

Shows operation status, error messages, and function menus. See ⇒ P.6 *"Panel Display"*.

### 5. [Program] key

Press to select the program mode. See ⇒ P.47 *"Program—Storing Your Copy Settings in Memory"*.

### 6. [Clear Modes] key

Press to clear the previously entered copy job settings.

### 7. [Energy Saver] key

Use to switch to and from Energy Saver mode. See ⇒ P.49 *"Energy Saver Mode—Saving Energy"*.

### 8. [Interrupt] key

Press to make interrupt copies during a copy run. See ⇒ P.49 *"Interrupt—Temporarily Stopping One Job to Copy Something Else"*.

### 9. Operation switch

Press this switch to turn the power on (the **On** indicator lights up). To turn the power off, press this switch again (the **On** indicator goes off).

### 10. [Auto Reduce/Enlarge] key

Enlarges or reduces the image automatically according to the specified paper size.

### 11. [Zoom] key

Changes the reproduction ratio in 1% steps.




### *12.* [Sort] key

Sort/Rotate Sort: automatically sorts copies.

### *13.* [Combine/Series Copy] key

Press to select "Combine" or "Series Copy".

### *14.* [Original Type] key

Press to select the type of your originals.

### *15.* [Lighter] and [Darker] keys and [Auto Image Density] key

Adjusts the copy image density.

### *16.* Selection keys

Press the key under the item you wish to select.

### *17.* ◁▷ keys (Cursor keys)

Press to select an item on the panel display.

### *18.* Operation panel for facsimile mode (for machines with optional fax function)

See the "Facsimile Reference".

### *19.* [Number] keys

Use to enter the desired number of copies and data for selected modes.

Use the [#] key to enter data in selected modes.

### *20.* [Clear/Stop] key

While entering numbers, press to cancel a number to have entered. While copying, press to stop copying.

### *21.* [Start] key

Press to start copying. Use to set the Auto Start. See ⇒ P.50 *"Auto Start—Entering Copy Job Settings During the Warm-up Period"*.

### *22.* Function keys

Press to change modes. To use copy functions, press the [Copy] key.

### *23.* Indicators (with the printer option)

These indicators shows the status of the printer.

See the "Printer Reference".

# Panel Display

The panel display shows operational status, error messages, and function menus.

**Important**

❒ Do not apply a strong shock or force of about 30N (about 3kgf) or more to the panel display. Otherwise, the display might be damaged.

**Note**

❒ When you select or specify an item on the panel display, it is highlighted like Auto.

❒ Keys appearing as OK cannot be used.

❒ By default, the machine is in Copy mode when you switch on. This can be changed. See "Settings You Can Change With The User Tools" of the System Settings.

## Displays and Key Operations

### ❖ Copy initial display




*1.* **The machine status and messages appear here.**

*2.* **Items which can be selected or specified.**

*3.* **These four keys correspond to the keys that are in the bottom line of the display (e.g.[Reduce], [Enlarge], and [100%] in the above display). Press the relevant key to select a key in the display.**

*4.* **Number of copies set.**

*5.* **Setting for this function.**

*6.* **Press these keys to select an item on the display.**

- To move the selection to the left, press the ◁ key.
- To move the selection to the right, press the ▷ key.

### ❖ Function menu display




*1.* **Displays operational status or message.**

*2.* **Displays items which can be selected or specified.**

### ❖ Common keys

| | |
|---|---|
| **[OK]** | Sets a selected function or entered value and returns to the previous display. |
| **[Cancel]** | Cancels a selected function or entered value and returns to the previous display. |
| **[↑Prev.][↓Next]** | When there are too many items fit on the display, use these keys to move between pages. |
| ◁▷ | Press to highlight the selection you wish to select. |
| **[Prev Menu]** | Press to return to the previous menu. |
| **[Exit]** | Sets a selected function or entered value and returns to the initial display. |

# Starting the Machine

To start the machine, turn on the operation switch.

**Note**

❒ This machine automatically enters Energy Saver mode or turns itself off if you do not use the machine for a while. See "08. Energy Saver Timer", "09. Auto Off Timer" of the System Settings.

**Power switches**

This machine has two power switches: See ⇒ P.1 *"Guide to Components"*.

❖ **Operation switch (right side of the operation panel)**

The Machine only with Fax or Printer option:
Turn on this switch to activate the machine. When the machine has warmed up, you can make copies or send faxes.

❖ **Main power switch (left side of the front panel)**

The machine only with copy feature:
Turn on this switch to activate the machine. Turn off this switch to shut off.
The machine with Fax or Printer option:
Do not touch the main power switch. It should be used only by a service representative when the optional fax unit is installed.

**Important**

❒ If you leave the main power switch off for more than about one hour, all fax files in memory will be lost. See "Turning Off The Power" of the Facsimile Reference.

## When the Machine Only with Copy Feature

### Turning on the power

**1** **Make sure that the power cord is plugged into the wall outlet firmly.**

**2** **Turn the main switch on.**



THYH240E

The panel display will come on.




**Note**

❒ During the warm-up period (less than 30 seconds.), you can use the Auto Start function. See ⇒ P.50 *"Auto Start—Entering Copy Job Settings During the Warm-up Period"*.

### When the machine is set for user codes

1 Enter your user code using the [Number] keys. Then press the [#] key.

**Note**

❒ To prevent others from making copies with your user code, press the [Clear Modes] key and the [Clear/Stop] key simultaneously after copying.

**Reference**

For setting user codes, see ⇒ P.81 *"1. General Features4/4"*.

### When the [Energy Saver] indicator is lit

The machine is in Energy Saver mode.

1 Press the [Energy Saver] key.

The machine will return to the ready condition.

**Note**

❒ The machine will also return to the ready condition when an original is set in the document feeder, or when the platen cover or document feeder is opened.

**Reference**

See "08. Energy Saver Timer" of the System Settings.

### Turning off the power

1 Turn the main switch off.



THYH240E

# When the Machine with Fax or Printer Option

## Turning on the power

**1** **Make sure that the power cord is plugged into the wall outlet firmly and the Main Power indicator is lit.**

**2** **Press the operation switch to make the On indicator light up.**




The panel display will come on.




### Note

❒ During the warm-up period (less than 30 seconds.), you can use the Auto Start function. See ⇒ P.50 *"Auto Start—Entering Copy Job Settings During the Warm-up Period"*.

## When the machine is set for user codes

**1** **Enter your user code using the [Number] keys. Then press the [#] key.**

### Note

❒ To prevent others from making copies with your user code, press the **[Clear Modes]** key and the **[Clear/Stop]** key simultaneously after copying.

### Reference

For setting user codes, see ⇒ P.81 *"1. General Features4/4"*.

## When the [Energy Saver] indicator is lit

The machine is in Energy Saver mode.

**1** **Press the [Energy Saver] key.**

The machine will return to the ready condition.

### Note

❒ The machine will also return to the ready condition when an original is set in the document feeder, or when the platen cover or document feeder is opened.

### Reference

See "08. Energy Saver Timer" of the System Settings.

## Turning off The power

**1** Turn the operation switch off.




**Important**

- If you want to unplug the power cord or turn off the main power switch, make sure that the remaining memory space indicates 100% on the display for facsimile mode.
- Fax files stored in memory will be lost an hour after you turn the main power switch off or you unplug the power cord. See "Turning Off The Power" of the Facsimile Referencre.

# Changing Modes

You can use this machine not only as a copier, but optionally as a fax or printer machine as well. Press the **[Copy]** key to use copy functions, press the **[Fax]** key to use facsimile functions, or press the **[Printer]** key to use printer functions.






## Limitation

❒ You cannot switch modes in any of the following cases:

- When scanning in a fax message for transmission.
- During immediate transmission.
- When accessing the user tools.
- During interrupt copying.

# Originals

1

## Sizes and Weights of Recommended Originals

### ❖ Metric version

| Where original is set | Original Size | Original Weight |
|---|---|---|
| Exposure glass | Up to A3 | -- |
| Document feeder | A3 – A5 | 40 – 128g/m² |

### ❖ Inch version

| Where original is set | Original Size | Original Weight |
|---|---|---|
| Exposure glass | Up to 11" × 17" | -- |
| Document feeder | 11" × 17"<br>– 5 1/2" × 8 1/2" | 11 – 34 lb |

### Non-recommended originals for the document feeder

Setting the following originals in the document feeder might cause paper misfeeds or damage to the originals. Set these originals on the exposure glass.

- Originals other than those specified in ⇒ P.14 *"Sizes and Weights of Recommended Originals"*
- Stapled or clipped originals
- Perforated or torn originals
- Curled, folded, or creased originals
- Pasted originals
- Originals with any kind of coating, such as thermal fax paper, art paper, aluminum foil, carbon paper, or conductive paper
- Originals with indexes, tags, or other projecting parts
- Sticky originals such as translucent paper
- Thin original that has low stiffness
- Originals of inappropriate weight ⇒ P.14 *"Sizes and Weights of Recommended Originals"*
- Bound originals such as books
- Transparent originals such as OHP transparencies or translucent paper

## Sizes Difficult to Detect

It is difficult for the machine to detect the sizes of the following originals, so select the paper size manually.

- Originals with indexes, tags, or other projecting parts
- Transparent originals such as OHP transparencies or translucent paper
- Dark originals with many letters and drawings
- Originals which partially contain solid image
- Originals which have solid image at their edges
- Originals other than those (with ○) in the table below. See ⇒ P.15 *"Sizes detectable by the Auto Paper Select"*.

### Sizes detectable by the Auto Paper Select

#### ❖ Metric version

| Size / Place of original | A3 | B4 | A4 | B5 | A5 | 11" × 17" | 8 1/2" × 14" | 8 1/2" × 11" | 5 1/2" × 8 1/2" | 8 1/2" × 13" |
|---|---|---|---|---|---|---|---|---|---|---|
| Exposure glass | ○ | ○ | ○ | ○ | × | × | × | × | × | ○ |
| Document feeder | ○ | ○ | ○ | ○ | ○ | × | × | × | × | ○ |

#### ❖ Inch version

| Size / Place of original | A3 | B4 | A4 | B5 | A5 | 11" ×17 | 8 1/2" ×14" | 8 1/2" ×11" | 10" ×8" | 8 1/2" ×13" | 10" ×14" | 5 1/2" ×8 1/2" |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Exposure glass | × | × | × | × | × | ○ | ○ | ○ | ○ | ○ | ○ | × |
| Document feeder | × | × | × | × | × | ○ | ○ | ○ | × | × | ○ | ○ |

# Original Sizes and Scanning Area/Missing Image Area

## ❖ Exposure glass




## ❖ Document feeder




## Limitation

❒ Even if you correctly set originals in the document feeder or on the exposure glass, 0.5mm – 3.5mm margins on top and left sides or 0.5mm margins on botton and right sides might not be copied.

# Copy Paper

## Recommended Paper Sizes and Types



The following limitations apply to each tray:

| | Metric version | Inch version | Paper weight | Paper capacity |
|---|---|---|---|---|
| Paper tray (Tray 1)<br>(Adjust the paper size selector) | A3, A4, A5,<br>$8^1/_2$" × 11",<br>$8^1/_2$" × 13" | A4,<br>11" × 17",<br>$8^1/_2$" × 14",<br>$8^1/_2$" × 11",<br>$8^1/_2$" × 13" | 60 – 90 g/m², 16 – 24 lb | 250 sheets |
| Paper tray (Tray 1)<br>(Specify the size with "11.Special Pap." of the System settings.) | B4, B5,<br>8K*1,<br>16K*2,<br>11" × 17",<br>$8^1/_2$" × 14",<br>$8^1/_2$" × 11",<br>$8^1/_2$" × $5^1/_2$",<br>$7^1/_4$" × $10^1/_2$",<br>8" × 13",<br>$8^1/_4$" × 13",<br>8" × 10",<br>$8^1/_4$" × 14" | A3, B4,<br>A4, B5,<br>A5,<br>8K*1,<br>16K*2,<br>11" × 17",<br>$8^1/_2$" × $5^1/_2$",<br>$7^1/_4$" × $10^1/_2$",<br>8" × 13",<br>$8^1/_4$" × 13",<br>8" × 10",<br>$8^1/_4$" × 14" | | |
| Paper tray unit*3<br>(Tray 2, 3)<br>(Adjust the paper size selector) | A3, A4, 11" × 17",<br>$8^1/_2$" × 14", $8^1/_2$" × 11", | | | 500 sheets |
| Paper tray unit*3<br>(Tray 2, 3)<br>(Specify the size with "11.Special Pap." of the System settings.) | B4, B5, A5, 8K*1,<br>16K*2, $8^1/_2$" × $5^1/_2$",<br>$7^1/_4$" × $10^1/_2$", 8" × 13",<br>$8^1/_2$" × 13", $8^1/_4$" × 13",<br>8" × 10", 8" × $10^1/_2$",<br>$8^1/_4$" × 14", 10" × 15",<br>11" × 15", 10" × 14",<br>11" × 14" | | | |

*1 8K(Ba-Kai) = 267 × 340mm (10.6" × 15.4")

*2 16K(Shi-Lui-Kai) = 195 × 267mm (7.7" × 10.6")

*3 Paper tray unit is option.

| Bypass tray | Metric version | Inch version | Paper weight | Paper capacity |
|---|---|---|---|---|
| Standard size (Plain paper) | A4⬓, A5⬓ | $8^1/_2$" × 11"⬓ | 60 – 104 g/m², 16 – 27 lb | 100 sheets |
| | A3⬓, 8" × 13"⬓ | 11" × 17"⬓ | | 10 sheets |
| Standard size (Thick paper)*5 | A3⬓, A4⬓, A5⬓, 8" × 13"⬓ | 11" × 17"⬓, $8^1/_2$" × 11"⬓ | 105 – 162 g/m², 28 – 43 lb | 10 sheet |
| Standard size (Plain paper)*6 | A4⬓, B5⬓⬓, A5⬓, B6⬓, 16K*2⬓⬓, $8^1/_2$" × 11"⬓⬓, $8^1/_2$" × $5^1/_2$"⬓, $7^1/_4$" × $10^1/_2$"⬓ | A4⬓⬓, B5⬓⬓, A5⬓⬓, B6⬓, 16K*2⬓⬓, $8^1/_2$" × 11"⬓, $8^1/_2$" × $5^1/_2$"⬓, $7^1/_4$" × $10^1/_2$"⬓⬓ | 60 – 104 g/m², 16 – 27 lb | 100 sheets |
| | B4⬓, 8K*1⬓, 11" × 17"⬓, $8^1/_2$" × 14"⬓, $8^1/_2$" × 13"⬓, $8^1/_4$" × 13"⬓ | A3⬓, B4⬓, 8K*1⬓, $8^1/_2$" × 14"⬓, 8" × 13"⬓, $8^1/_2$" × 13"⬓, $8^1/_4$" × 13"⬓ | | 10 sheets |
| Standard size (Thick paper)*5*6 | B4⬓, A4⬓, B5⬓⬓, A5⬓, B6⬓, 8K*1⬓, 16K*2⬓⬓, 11" × 17"⬓, $8^1/_2$" × 14"⬓, $8^1/_2$" × 13"⬓, $8^1/_2$" × 11"⬓⬓, $8^1/_2$" × $5^1/_2$"⬓, $7^1/_4$" × $10^1/_2$"⬓, $8^1/_4$" × 13"⬓ | A3⬓, B4⬓, A4⬓⬓, B5⬓⬓, A5⬓⬓, B6⬓, 8K*1⬓, 16K*2⬓⬓, $8^1/_2$" × 14"⬓, $8^1/_2$" × 11"⬓, $8^1/_2$" × $5^1/_2$"⬓, $7^1/_4$"×$10^1/_2$"⬓⬓, 8" × 13"⬓, $8^1/_2$" × 13"⬓, $8^1/_4$" × 13"⬓ | 105-162 g/m², 28 – 43 lb | 10 sheets |

*1 8K(Ba-Kai) = 267 × 340mm (10.6" × 15.4")

*2 16K(Shi-Lui-Kai) = 195 × 267mm (7.7" × 10.6")

*5 When you set thick paper in the bypass tray, you have to specify the paper type **[Thick]**. See ⇒ P.39 *"Copying from the Bypass Tray"*

*6 When you set these standard size paper in the bypass tray, you have to specify the standard size. See ⇒ P.39 *"Copying from the Bypass Tray"*

| Bypass tray | Metric version | Inch version | Paper weight | Paper capacity |
|---|---|---|---|---|
| Custom size*7 | Vertical: 90–305 mm<br>Horizontal: 148 –1,260 mm | Vertical: 3.5" – 12.0" mm<br>Horizontal: 5.8"–49.6" mm | 52–157 g/m², 16 – 42 lb | 10 sheet |
| | Postcards, adhesive labels, translucent paper, OHP transparencies | | | |
| Custom size*7 Envelopes | Com#10 Env<br>241.3 × 104.8 mm, 9.5" × 4.2" | | 72–90 g/m², 19 – 24 lb | |
| | C6 Env<br>162 × 114 mm, 6.4" × 4.5" | | | |
| | DL Env<br>220 × 110 mm, 8.7" × 4.4" | | | |
| | Monarch Env<br>190.5 × 98.4 mm, 7.5" × 3.9" | | | |

*7 When you set these custom size paper in the bypass tray, you have to specify the size. See ⇒ P.39 *"Copying from the Bypass Tray"*.

**Important**

❒ If you use damp or curled paper, a misfeed might occur. In such a case, try turning over the paper stack in the paper tray. If there is no improvement, change to copy paper with less curl.

**Note**

❒ Post cards should be fed from the bypass tray.

❒ If OHP transparencies and translucent paper gets double-fed, set pages one sheet at a time.

❒ If you load paper of the same size and in the same direction in two or more trays, the machine automatically shifts to another tray when the tray in use runs out of paper. This function is called Auto Tray Switch. This saves interrupting a copy run to replenish paper even when you make a large number of copies. You can cancel this setting. See "13. Auto Tray Switch" of the System Settings.

**Reference**

If you want to add paper, see ⇒ P.66 *"Loading Paper"*.

If you want to change the paper size, see ⇒ P.72 *"Changing the Paper Size"*.

## Envelopes

**Note**

- When copying on envelopes, use the bypass tray and specify the size. See⇒ P.43 *"When Copying onto Envelopes"*.
- Specification of envelopes are follows:

| | Metric version | Inch version |
|---|---|---|
| Weight | 72 - 90 g/m$^2$ | 19 - 24 lb |
| Recommended weight and size | 72 g/m$^2$, 114 × 162 mm (C6 Env) | 24 lb, $3^7/_8$" × $7^1/_2$" (Monarch) |

- You can load up to 10 envelopes (72 - 90 g/m$^2$, 19 - 24 lb) onto the bypass tray at a time, without forcibly preassign them. However, make sure that the envelopes are not damp, and that the top of the stack is not higher than the limit mark on the side guide ⇒ P.43 *"When Copying onto Envelopes"*.
- Load the envelopes with the flaps aligned to the right side fence. The flaps should be securely folded down.
- Make sure that there is no air in the envelopes before setting.
- To get the better copy quality, it is recommended that you set the right, left, top, and bottom margin, to at least 15 mm (0.6") each.
- Do not copy on both sides of envelopes.
- Load only one size and type of envelope at a time.
- Before loading envelopes, flatten the leading edges (side being fed into the printer) of them by running a pencil or ruler across them.

❒ Before setting envelopes, make sure that they are rectangular in shape. Refer to the following illustrations.

| Metric version | Inch version |
|---|---|
|   |   |
| ①Good construction for envelopes<br>②Poor construction for envelopes | ①Good construction for envelopes<br>②Poor construction for envelopes |

❒ Avoid using the non-supported envelopes listed on P.21 *"Non-recommended Paper"*

**Limitation**

❒ Even if you use the reccommended types of envelope as notes above, copied envelopes may come out wrinkled or smudged.

## Non-recommended Paper

⚠ ***CAUTION:***

- *Do not reuse stapled paper. Do not use aluminum foil, carbon-containing paper or other conductive paper. Otherwise, a fire might occur.*

**Important**

❒ Do not use paper with any kind of coating such as:

- Thermal fax paper
- Art paper
- Aluminum foil
- Carbon paper
- Conductive paper

❒ Otherwise, a fault might occur.

❒ Do not use copy paper that has been already copied on. Otherwise, a fault might occur.

**Note**

❒ Do not use the following type of paper because a paper misfeed might occur.
- Bent, folded, or creased paper
- Torn paper
- Slippery paper
- Perforated paper
- Rough paper
- Thin paper that has low stiffness
- Paper with much paper dust on its surface

❒ Do not use envelopes in the following conditions.
- damp
- excessively curled or twisted
- stuck together
- damaged in any way
- with stamps attached
- with windows, holes, perforations, cutouts, or embossing
- with metal clasps, string ties, or metal folding bars
- designed to be interlocked
- with nicked edges of bent corners
- with rough, cockle, or laid finishes
- with any exposed adhesive, when the flap is in the sealed or closed position.

❒ If you make a copy on rough grain paper, the copy image might be blurred.

❒ Do not use paper which has been copied or printed on.

## Paper Storage

**Note**

❒ When storing paper, the following precautions should always be followed:
- Do not store paper where it will be exposed to direct sunlight.
- Avoid storing paper in humid areas (humidity: 70% or less).
- Store on a flat surface.

❒ Keep open reams of papers in the package, and store as you would unopened paper.

❒ Under high temperature and high humidity, or low temperature and low humidity conditions, store papers in a vinyl bag.

# Toner Cartridge



## Handling Toner

⚠ ***WARNING:***

- ***Do not incinerate used toner or toner containers. Toner dust might ignite when exposed to an open flame. Dispose of the used toner containers according to local regulations for plastics.***

⚠ ***CAUTION:***

- *Do not eat or swallow toner.*
- *Keep toner (used or unused) and toner containers out of reach of children.*

⚠ ***CAUTION:***

- *This machine has been tested for safety using this supplier's parts and consumables. We recommend you only use these specified supplies.*

**Important**

❒ If you use toner cartridge other than that recommended, a fault might occur.

**Reference**

If you want to replace the toner cartridge, see ⇒ P.67 "*Replacing the Toner Cartridge*".

## Toner Storage

**Note**

❒ When storing the toner cartridge, the following precautions should always be followed:

- Store the toner cartridge containers in a cool, dry place free from direct sunlight.
- Do not store the toner cartridge where it will be exposed to heat.
- Do not eat or swallow toner, and keep it out of reach of children.
- Store on a flat surface.

# Basic Procedure

**1** When the machine is set for user code, enter the user code with the [Number] keys and then press the [#] key.

**Reference**

See ⇒ P.49 *"User Codes"*.

**2** Make sure that the machine is in Copy mode.




**Note**

❒ If not, press the [Copy] key.

**3** Make sure that there are no previous settings remaining.

**Note**

❒ To clear settings, press the [Clear Modes] key.

**4** Set your originals.

**Reference**

See ⇒ P.27 *"Setting Originals"*.

**5** Set your desired settings.

**6** Enter the number of copies required with the [Number] keys.




**Note**

❒ The maximum copy quantity can be set between 1 and 99 (default: *99*). See "05. Max. Copy Q'ty" in ⇒ P.78 *"1. General Features 1/4"*.

❒ To change the number entered, press the [Clear/Stop] key and enter the new number.

**7** Press the [Start] key.

The machine starts copying.

**Important**

❒ If the number of delivered copies exceeds the delivery tray capacity, paper jam might occur. Remove copies before the stack gets higher than the copy delivery exit.

**Note**

❒ To stop the machine during the multi-copy run, press the [Clear/Stop] key.

❒ To return the machine to the initial condition after copying, press the **[Clear Modes]** key.

❒ The maximum tray capacity is as follows. When the number of copies exceeds the tray capacity, remove copies from the tray.

| | |
|---|---|
| Internal tray 1 | 250 sheets (80g/$m^2$, 20 lb) |
| | When Internal tray 2 installed: 125 sheets (80g/$m^2$, 20 lb) |
| Internal tray 2 | 125 sheets (80g/$m^2$, 20 lb) |

❒ The maximum tray capacity might also be reduced when copy paper is considerably curled.

### Auto Reset

The machine returns to its initial condition automatically after your job is finished, after a certain period of time. This function is called "Auto Reset".

**Note**

❒ You can change the Auto Reset time. See "09. Copy Auto Reset" in ⇒ P.80 *"1. General Features $^3/_4$"*.

### Auto Off

The machine turns itself off automatically after your job is finished, after a certain period of time. This function is called "Auto Off".

**Note**

❒ You can change the Auto Off time. See "09. Auto Off Timer" in the System Settings.

❒ You can change the default settings for basic functions. See ⇒ P.78 *"Settings You Can Change with the User Tools"* and "USER TOOLS (SYSTEM SETTINGS)" in the System Settings.

# Setting Originals

### Limitation

❒ Set the original after correction fluid and ink has completely dried. Not taking this precaution could mark the exposure glass and cause marks to be copied.

### Note

❒ Basically the originals should be aligned to the rear left corner. However, some copy functions may produce different results depending on the direction of the originals. For details, see explanations of each function.

| Originals | Set in the document feeder | Set on the exposure glass |
|---|---|---|
|  | | |



### Reference

See ⇒ P.14 *"Originals"*.

## Setting Originals on the Exposure Glass

**1** **Lift the platen cover or the document feeder.**

### Note

❒ Be sure to open the platen cover or the document feeder by more than 30°, otherwise the original size might not be detected correctly.

**2** **Set the original face down on the exposure glass. Slide your original up to the blue scale, then into the left corner of the exposure glass as shown.**




1: Reference mark

2: Scale

**3** **Lower the platen cover or the document feeder.**

# Setting Originals in the Document Feeder

**Important**

- When copying onto translucent paper, set your originals one at a time in the document feeder to avoid multiple feeds and damage to originals. See⇒ P.29 *"Setting one original at a time (SADF) mode"*

**Note**

- Do not stack originals above the limit mark.
- The original might become dirty if it is written with a pencil or similar tools.
- If your original contains pages of different sizes, set the pages one at a time in the ADF. See⇒ P.29 *"Setting one original at a time (SADF) mode"*.
- When setting documents whose sizes cannot be scanned from the ADF, select Custom Size. See ⇒ P.29 *"Setting Originals When Auto Paper Select Cannot Recognize the Size"*.

**Reference**

Regarding originals that the document feeder can handle, see ⇒ P.14 *"Originals"*.

## Setting a stack of originals in the document feeder

**1 Set the aligned originals face up into the document feeder.**




**Note**

- To avoid a multi-sheet feed, shuffle the originals before setting them in the document feeder.

**2 Adjust the guide to the original size.**

## Setting one original at a time (SADF) mode

**Important**

- ❒ Hold the document from the front when setting it. If your hand covers the internal sensor, it will not operate correctly and the original could be damaged.
- ❒ When setting pages of documents 1 page at a time in the ADF using Auto Paper Select and Auto Reduce/Enlarge, these features adapt to the size of the scanned original.

**1 Set one original face up into the document feeder. Then, press the [Start] key.**

The Auto Feed indicator is lit.

**2 Set the next original while the Auto Feed indicator is lit.**

The second and subsequent originals can be fed automatically without pressing the **[Start]** key.



THYH260E

**Note**

- ❒ You can adjust the time the machine waits before being ready for the next original. See "SADF Auto Reset" in ⇒ P.82 *"2. Input/ Output"*.

## Setting Originals When Auto Paper Select Cannot Recognize the Size

When you wish to use Auto Reduce/ Enlarge when setting non-standard size documents in the ADF, specify the size of your original using the following procedure.

**Important**

- ❒ Be sure to press the **[Clear Modes]** key after copying non-standard size originals to clear any settings. Not taking this precaution could result in damage to originals set in the ADF.

**Limitation**

- ❒ You cannot specify the original size when using Auto Paper Select.
- ❒ Acceptable Document Sizes
  Vertical:105 - 297mm
  (4.1"-11.7")
  Horizontal: 128 - 1,260mm
  (5.0"-17.0")

**1 Set the aligned originals face up into the document feeder.**

**2 Adjust the guide to the original size.**



THYH080E

**Note**

❒ To avoid a multi-sheet feed, shuffle the originals before settings them in the document feeder.

❒ You can set one original at a time. See ⇒ P.29 *"Setting one original at a time (SADF) mode"*

**3** **Press the ◁▷ key to choose the tray from the paper tray, paper tray unit (option), or the bypass tray.**

**4** **Press the [#] key.**

### When you select tray1-3

❶ **Enter the Horizontal size with the [Number] keys. Then press the [#] key.**

**Note**

❒ To change the number enterd, press the **[Clear/Stop]** key and enter the new number.

❷ **Enter the Vertical size with the [Number] keys. Then press the [OK] key.**




**<⎙✳> appeared in exchange for [Auto] after the sizes setted.**




**Note**

❒ To change the number enterd, press the **[Clear/Stop]** key and enter the new number.

### When you select the bypass tray

❶ **Press the [#] key.**

❷ **Press the [Orig. Size] key.**




❸ **Enter the Horizontal size with the [Number] keys. Then press the [#] key.**

**Note**

❒ To change the number enterd, press the **[Clear/Stop]** key and enter the new number.

❹ **Enter the Vertical size with the [Number] keys. Then press the [OK] key.**




**<⎙✳> appeared in exchange for [Auto] after the size setted.**




**Note**

❒ To change the number enterd, press the **[Clear/Stop]** key and enter the new number.

# Basic Functions

The following basic functions are explained in this section.

❖ **Adjusting Copy Image Density**
Auto and Manual Image Density

❖ **Selecting Original Type Setting**
Text, Text·Photo, Photo

❖ **Selecting Copy Paper**
Auto Paper Select and Manual Paper Select

❖ **Auto Reduce/Enlarge**
The machine can choose an appropriate reproduction ratio based on the paper and original sizes you select.

**Note**

❒ You can select functions to be activated when Auto Reset is turned on, when Energy Saver is turned off, or after the machine is powered on. See ⇒ P.78 *"1. General Features 1/4"*.

❒ You can change default settings for basic functions. See ⇒ P.78 *"Settings You Can Change with the User Tools"*.

❒ You can have the settings stored in program 10 used as the initial settings (when the initial display is shown). See ⇒ P.47 *"Program"*, P.80 *"10.Initial Mode set"*

## Adjusting Copy Image Density

You can adjust the copy image density to match your originals.

There are three types in this function:

❖ **Auto Image Density**
The machine automatically adjusts the image density.

❖ **Manual Image Density**
If you require darker or lighter copies, adjust the image density yourself.

❖ **Combined Auto and Manual Image Density**
Use when copying originals with a dirty background (such as newspapers). You can adjust the foreground density while leaving the background unchanged.

**1 Select one of Image Density modes.**

Auto image density

**❶ Make sure that the Auto Image Density indicator is lit.**




**Note**

❒ If not, press the **[Auto Image Density]** key.

### Manual image density

❶ **Press the [Auto Image Density] key to cancel it.**

❷ **Press the [Lighter] or [Darker] key to adjust the image density.**




THYS780E

### Combined auto and manual image density

❶ **Make sure that the Auto Image Density indicator is lit.**

❷ **Press the [Lighter] or [Darker] key to adjust the density.**




THYS780E

## Selecting Original Type Setting

Select one of the following types to match your originals:

❖ **Text**
Select this mode when your originals contain only letters (no pictures).

❖ **Text·Photo**
Select Text·Photo when your originals contain photographs or pictures with letters.

❖ **Photo**
Delicate tones of photographs and pictures can be reproduced with this mode.

If you do not select any mode, your originals will be scanned with the settings suitable for text originals (Text mode).

**1 Press the [Original Type] key and select the original type.**




THYS640E

**Note**

❒ Press the **[Original Type]** key to step through the following types:

| | |
|---|---|
| No indicator lit | Text |
| Text·Photo indicator lit | Text·Photo |
| Photo indicator lit | Photo |

❒ You can specify whether or not the Toner Saving feature is enabled. See *"08. Image Adjustment"* in ⇒ P.79 *"1.Generral Features 2/4"*.

❒ When the Toner Saving mode is specified , the whole image gets lighter.

❒ When you cannot make clear copies, you can adjust the quality level of copies for each of the original types (Text, Text·Photo, Photo). See ⇒ P.63 *"If You Cannot Make Clear Copies"*.

## Selecting Copy Paper

There are two ways to select copy paper:

### ❖ Auto Paper Select

The machine selects a suitable size of copy paper automatically based on the original size and the reproduction ratio.

**Note**

❒ When the original is set at a different direction from the copy paper in the paper tray with Auto Tray Switch mode ON, the machine automatically rotates the original image by 90° to match the copy paper direction (the paper tray unit (option) is required.). This applies to the following paper sizes:

| | |
|---|---|
| Metric version | A4 ▯▭, B5 ▯▭ |
| Inch version | $8^1/_2$" × 11" ▯▭ |

**Reference**

For Auto Tray Switch, see "13. Auto Tray Switch" in the System Settings.

### ❖ Manual Paper Select

You can select the desired copy paper size manually. You can also select the bypass tray.

**Reference**

See ⇒ P.39 *"Copying from the Bypass Tray"*.

**Note**

❒ When you use Auto Paper Select, refer to the following table for possible copy paper sizes and directions. (if the ratio is 100%)

2

### ❖ Metric version

| Where original is set | Original size and direction |
|---|---|
| Exposure glass | A3 ⧉, B4 ⧉, A4 ⧉⧉, B5 ⧉⧉, 8 1/2" × 13" ⧉ |
| Document feeder | A3 ⧉, B4 ⧉, A4 ⧉⧉, B5 ⧉⧉, A5 ⧉⧉, 8 1/2" × 13" ⧉ |

### ❖ Inch version

| Where original is set | Original size and direction |
|---|---|
| Exposure glass | 11" × 17" ⧉, 8 1/2" × 14" ⧉, 8 1/2" × 11" ⧉⧉, 10" × 8" ⧉, 8 1/2" × 13" ⧉, 10" × 14" ⧉ |
| Document feeder | 11" × 17" ⧉, 8 1/2" × 14" ⧉, 8 1/2" × 11" ⧉⧉, 5 1/2" × 8 1/2" ⧉⧉, 10" × 14" ⧉ |

❒ For some originals, the original size might not be detected correctly. See ⇒ P.15 *"Sizes Difficult to Detect"*.

**1 Select the copy paper.**

## Auto paper select

**❶ Make sure that the Auto (Auto Paper Select) is selected.**




## Manual paper select

**❶ Select the paper tray or bypass tray by pressing ◀▶key.**






# Auto Reduce/Enlarge—Having the Machine Choose the Reproduction Ratios

The machine can choose an appropriate reproduction ratio based on the paper and original sizes you select.



### Note

❒ When you use Auto Reduce/Enlarge, refer to the following table for possible original sizes and directions:

#### ❖ Metric version

| Where original is set | Original size and direction |
|---|---|
| Exposure glass | A3 ⬓, B4 ⬓, A4 ⬒⬓, B5 ⬒⬓, 8 1/2" × 13" ⬓ |
| Document feeder | A3 ⬓, B4 ⬓, A4 ⬒⬓, B5 ⬒⬓, A5 ⬒⬓, 8 1/2" × 13" ⬓ |

#### ❖ Inch version

| Where original is set | Original size and direction |
|---|---|
| Exposure glass | 11" × 17" ⬓, 8 1/2" × 14" ⬓, 8 1/2" × 11" ⬒⬓, 10" × 8" ⬓, 8 1/2" × 13" ⬓, 10" × 14" ⬓ |
| Document feeder | 11" × 17" ⬓, 8 1/2" × 14" ⬓, 8 1/2" × 11" ⬒⬓, 5 1/2" × 8 1/2" ⬒⬓, 10" × 14" ⬓ |

❒ The reproduction ratios the machine will select are 50-200%.

❒ For some originals, the original size might not be detected correctly. See ⇒ P.15 *"Sizes Difficult to Detect"*.

❒ When you set original of two different size at a time, you must set one original at a time. See ⇒ P.29 *"Setting one original at a time (SADF) mode"*.

❒ Image Rotation is not available when copying onto A3 (11"×17") paper with the Enlarge feature. Set your original lengthwise when copying onto A3 (11"×17") paper with the Enlarge feature.

**1** **Press the [Auto Reduce/Enlarge] key.**



**2** Select the paper tray by pressing ◁▷.







**Note**

❒ The enlargment/reduction ratio automatically calculated to match the size of copy paper you have chosen is displayed.

# Sort

The machine can scan your originals into memory and automatically sort the copies.

There are two types in the Sort function:

### ❖ Sort

Copies can be assembled as sets in sequential order.



### ❖ Rotate Sort

Every other copy set is rotated by 90° and delivered to the copy tray.



### Limitation

❒ You cannot use the bypass tray with this function.

### Note

❒ To switch among Sort and Rotate Sort modes, access the user tools. See "5. Sort" in ⇒ P.82 "2. *Input/ Output*".

❒ The maximum tray capacity is as follows. When the number of copies exceeds the tray capacity, remove copies from the tray.

| | |
|---|---|
| Internal tray 1 | 250 sheets (80g/m$^2$,20lb) |
| | When Internal tray 2 installed: 125 sheets (80g/m$^2$,20lb) |
| Internal tray 2 | 125 sheets (80g/m$^2$,20lb) |

❒ The maximum tray capacity might be less than the above when you use the Rotate Sort.

❒ The maximum tray capacity might also be reduced when copy paper is considerably curled.

❒ The paper sizes that can be used in Sort function are as same as the sizes applied to Tray 1, 2, or 3. See ⇒ P.17 "*Copy Paper*".

❒ The paper sizes that can be used in Rotate Sort function are as follows:

| | |
|---|---|
| Metric version | A4 B5 |
| Inch version | $8^1/_2$" × 11" |

❒ To use the Rotate Sort function, two paper trays identical in size and different in direction ( ) are required (the paper tray unit (option) is required).

**1** **Press the [Sort] key.**




THYS070E

**2** **Enter the number of copy sets with the [Number] keys.**

**Limitation**

❒ The maximum number of sets is 99.

**3** **Set your originals.**

When setting a stack of originals in the document feeder

❶ **Set a stack of originals in the document feeder, then press the [Start] key.**

After all the originals are scanned, the copies are delivered to the tray.

**Note**

❒ The last page should be on the bottom.

❒ If an original is misfed while copying with the Sort feature, reset the remaining originals in the ADF starting with the jammed page.

When setting an original on the exposure glass or in the document feeder

**Reference**

⇒ P.29 *"Setting one original at a time (SADF) mode"*

❶ **Set the original, then press the [Start] key.**

**Note**

❒ Start with the first page to be copied.

❷ **Set the next original, then press the [Start] key.**

**Note**

❒ Set the original in the same direction as the first one.

❒ When you set an original in the document feeder, the second and subsequent originals can be fed automatically without pressing the [Start] key

❸ **After all originals are scanned, press the [#] key.**

The copies are delivered to the tray.

# Copying from the Bypass Tray

Use the bypass tray to copy onto OHP transparencies, adhesive labels, translucent paper, post cards, envelopes and copy paper that cannot be set in the paper tray.

### Note

❒ The machine can automatically detect the following sizes as standard size copy papers:

| | |
|---|---|
| Metric version | A3□, A4□, A5□, 8" × 13"□ |
| Inch version | 11" × 17"□, $8^1/_2$" × 11"□ |

❒ When you set the standard size paper except the sizes as above, you have to specify the standard size. See ⇒ P.41 *"When copying onto standard size copy paper"*.

❒ If you do not use the standard size copy paper, you should input vertical and horizontal dimensions. The sizes that you can input are as follows:

| | |
|---|---|
| Metric version | • Vertical: 90 – 305mm<br>• Horizontal: 148 – 1,260mm |
| Inch version | • Vertical: 3.5" – 12.0"<br>• Horizontal: 5.8" – 49.6" |

❒ To make copies onto OHP transparencies or thick paper (105 – 162g/$m^2$, 28 – 43lb), be sure to specity the paper type **[thick]**. See P.42 *"When copying onto OHP transparencies or thick paper"*.

❒ To make copies onto envelopes, See P.43 *"When Copying onto Envelopes"*.

### Reference

For details about paper capacity of the bypass tray, see ⇒ P.17 *"Copy Paper"*.



**1** **Open the bypass tray.**



THYH090E

**2** **Lift the paper hold lever.**




THYH100E

1: Paper hold lever

2: Extender

### Note

❒ Swing out the extender to support larger size copy paper.

**3 Lightly insert the copy paper face down until the it stops. Adjust the guides to copy paper size.**

The ≡ indicator on the display is automatically selected.




THYH110E

3: Paper guide

**Important**

- If the guides are not flush with the copy paper, a skew image or paper misfeeds might occur.

**Note**

- Do not stack paper over the limit mark; otherwise a skew image or paper misfeeds might occur.
- Fan paper to get air between the sheets and avoid a multi-sheet feed.
- When you set a OHP transparencies, make sure that its front and back faces are properly positioned.

**4 Lower the paper hold lever.**



THYH120E

## When copying onto custom size copy paper

**Important**

- You should specify the size of copy paper to avoid paper misfeeds.
- If you select Standard or Custom as the Paper Size setting, these functions will remain in effect even after Auto Clear or pressing the **[Clear Modes]** key. You can alter this behavior by changing *"12. Reset Bypass Set"*. See ⇒ P.80 *"1. General Features 3/4"*.

**❶ Make sure the [Bypass] is selected.**




**❷ Press the [#] key.**

**❸ Press the [Pap. Size] key.**






THYS670E

**❹ Select [Custom Size] with the ◀▶ keys. Then press the [Custom] key.**



THYS760E

❺ **Enter the horizontal size of the paper with the [Number] keys, then press the [#] key.**

**Note**

❒ To change the number entered, press the **[Clear/Stop]** key and enter the new number.




4: Horizontal

5: Vertical

❻ **Enter the vertical size of the paper with the [Number] keys, then press the [OK] key.**



**Note**

❒ To change the number entered, press the **[Clear/Stop]** key and enter the new number.

❒ When you specify the paper size, 大 appears on the display to indicate bypass tray copying.

❼ **Press the [Exit] key.**






## When copying onto standard size copy paper

**Important**

❒ If you select Standard or Custom as the Paper Size setting, these functions will remain in effect even after Auto Clear or pressing the **[Clear Modes]** key. You can alter this behavior by changing *"12. Reset Bypass Set"*. See ⇒ P.80 *"1. General Features 3/4"*.

❶ **Make sure the [Bypass] is selected.**




❷ **Press the [#] key.**

❸ **Press the [Pap. Size] key.**



❹ **Select [Std. size] with the ◁▷ keys. Then press the [Custom] key.**



THYS760E

❺ **Select the desired size with the [NEXT], [Prev.] or the ◁▷ keys, then press the [OK] key.**



❻ **Press the [Exit] key.**






## When copying onto OHP transparencies or thick paper

**Important**

❐ If you select Thick Paper/Special Paper as the Paper Type setting, these functions will remain in effect even after Auto Clear or pressing the **[Clear Modes]** key. You can alter this behavior by changing *"12. Reset Bypass Set"*. See⇒P.80 *"1. General Features 3/4"*.

❶ **Make sure the [Bypass] is selected.**

❷ **Press the [#] key.**

❸ **Press the [Pap. Type] key.**






THYS760E

❹ **Select [Thick] with the ◁▷ keys. Then, press the [OK] key.**



THYS860E

**Note**

❐ Only select Special Paper when you cannot make clean copies. See⇒P.63 *"If You Cannot Make Clear Copies"*

❺ **Press the [Exit] key.**




**Reference**

To go on to specify a paper size, press the **[Pap. Size]** key.

See ⇒ P.37 *"When copying onto custom size copy paper"*.

See ⇒ P.38 *"When copying onto standard size copy paper"*.

**5** **Set your originals and press the [Start] key.**

**Important**

❒ When copying onto OHP transparencies, remove copied sheets one by one.

**Note**

❒ Push on the engraved center point of the bypass tray to close it.




## When Copying onto Envelopes

**Important**

❒ If you select Thick Paper as the Paper Type setting and select Standard or Custom as the Paper Size setting, these functions will remain in effect even after Auto Clear or pressing the **[Clear Modes]** key. You can alter this behavior by changing "12. Reset Bypass Set". See⇒P.80 *"1. General Features 3/4"*.

**Reference**

For detail about the recommended envelopes, see ⇒P.17 *"Copy Paper"*

**1** **Open the bypass tray.**



2

**2** **Lift the paper hold lever. Then swing out the extender.**




THYH100E

1: Paper hold lever

2: Extender

**3** **Lightly insert the envelopes face down and the sides of the flaps on the right as shown below.**




THYH370E

**Important**

- ❒ Make sure that the envelope flap are securely folded down, and that there is no air inside the envelopes.
- ❒ You can load up to 10 envelopes (72-90g/m$^2$, 19-24 lb). Do not stack envelope over the limit mark, otherwise a skew image or paper misfeeds might occur.

**4** **Lower the paper hold lever.**



THYH380E

**5** **Make sure the [Bypass] is selected.**




**6** **Press the [#] key.**

**7** **Press the [Pap.Type] key.**




THYS760E

**8** **Select [Thick] with the ◁▷ keys. Then press the [OK] key.**




THYS860E

**9** **Press the [Pap.Size] key.**




**10** **Select [Custom Size] with the ◁▷ keys. Then press the [Custom] key.**




**11** **Enter the horizontal size of the envelope with the [Number] keys, then press the [#] key.**




4: Horizontal

5: Vertical

**12** **Enter the vertical size of the envelope with the [Number] keys, then press the [OK] key.**




**Note**

❒ You have to enter the size as follows:

❖ **Metric version**

| | Horizontal × Vertical |
|---|---|
| Com #10 Env | 241.3 × 104.8mm |
| C6 Env | 162 × 114mm |
| DL Env | 220 × 110mm |
| Monarch Env | 190.5 × 98.4mm |

❖ **Inch version**

| | Horizontal × Vertical |
|---|---|
| Com #10 Env | 9.5" × 4.2" |
| C6 Env | 6.4" × 4.5" |
| DL Env | 8.7" × 4.4" |
| Monarch Env | 7.5" × 3.9" |

❒ To change the number entered, press the **[Clear/Stop]** key and enter the new number.

❒ When you specify the paper size, 区 appears on the display to indicate bypass tray copying.

13 **Press the [EXIT] key.**




14 **Set your originals and press the [Start] key.**

**Note**

❒ Push on the engraved center point of the bypass tray to close it.



# Program—Storing Your Copy Settings in Memory

You can store frequently used copy job settings in machine memory, and recall them for future use.

❖ **Storing Your Settings**
You can store your settings you frequently use.

❖ **Deleting A Program**
You can delete a stored program.

❖ **Recalling A Program**
You can recall a stored program.

**Note**

❒ You can store up to ten programs.

❒ Paper settings are stored based on paper size. So if you place more than one paper tray of a same size, the paper tray prioritized with the user tools will be selected first. See "12. Pap.Tray Priority" of the System Settings.

❒ Programs are not cleared by turning the power off or by pressing the **[Clear Modes]** or **[Energy Saver]** key. They are canceled only when you delete or overwrite them with another program.

**Limitation**

❒ You cannot store the number of copies in a program.

## Storing Your Settings

**1** **Edit the copy settings so that all functions you want to store in this program are selected in a program.**

**2** **Press the [Program] key.**




**3** **Press the [Store] key.**




**4** **Select the program number you want to store these settings in with the ◁▷ keys. Then, press the [OK] key.**

When the settings are successfully stored, the ◈ indicator appears.




**Note**

❒ Program numbers with ◈ already have settings in them.

❒ If this program number is already being used, the machine will ask you if you wish to overwrite it - press the **[Yes]** or **[No]** key.

## Deleting a Program

You can delete a stored program.

**1** **Press the [Program] key.**




THYS090E

**2** **Press the [Delete] key.**






THYS760E

**3** **Select the program number you want to delete with the ◁▷ keys. Then press the [OK] key.**






THYS860E

**4** **Press the [Yes] key.**






THYS800E

**Note**

❒ To cancel the deletion, press the **[No]** key.

**5** **To delete another program, repeat steps 3 and 4.**

**6** **Press the [Exit] key.**



THYS800E

## Recalling a Program

You can recall a stored program.

**1** **Press the [Program] key.**




THYS090E

**2** **Select the program number you want to recall with the ◁▷ keys. Then, press the [OK] key.**

The stored settings are displayed.






THYS860E

**Note**

❒ Only programs with ◈ contain a program.

**3** **Set your originals, enter the number of copies required with the [Number] keys, then press the [Start] key.**

# Other Functions

## Energy Saver Mode—Saving Energy

If you do not operate the machine for a certain period after copying, or when you press and hold the **[Energy Saver]** key for more than one second, the display disappears and the machine enters Energy Saver mode. When you press the **[Energy Saver]** key again, the machine returns to the ready condition. In Energy Saver mode, the machine uses less electricity.

The Energy Saver mode makes a two-step reduction in electricity: one for the period up to the time set for Low Power mode, the other for the period after that time.
You can select the Energy Saver Mode power level.

**Note**

❒ The period for which the machine remains in Energy Saver mode (i.e. the period until the mode is turned off to return to the ready condition) varies with the effectiveness of energy saving.

❒ If you press the **[Energy Saver]** key during the operation, the current settings will be cleared.

**Reference**

See "07. Energy Saver Level" and "08. Energy Saver Timer" of the System Settings.

## Interrupt—Temporarily Stopping One Job to Copy Something Else

You can make urgently needed copies during a multi-copy run.

**1** **Press the [Interrupt] key.**

The key indicator lights.

**2** **Remove the originals currently set for copying, and set your originals for interrupt copying. Make your copies.**

**3** **After interrupt copying, remove the originals for interrupt copying and the copies.**

**4** **Press the [Interrupt] key again.**

The key indicator goes off.

**5** **Reset the previous originals. Then, press the [Start] key.**

**Note**

❒ The previous copy settings are recalled and the previous copy job can be resumed by pressing the **[Start]** key.

**Limitation**

❒ You cannot choose the sort or combine copy function in interrupt copying

## User Codes

If the machine is set to use the User Code function, operators must input their user codes before the machine can be operated. The machine keeps

count of the number of copies made under each user code.

**Note**

❒ When the machine is set for user codes, the machine will prompt you for your user codes after the power switch is on or the Auto Reset comes into effect.

❒ To prevent others from making copies using your user code, press the [Clear Modes] and [Clear/Stop] keys simultaneously after copying.

**Reference**

For setting user codes, see ⇒ P.81 *"1. General Features 4/4"*.

## Auto Start—Entering Copy Job Settings During the Warm-up Period

If you press the [Start] key during the warm-up period, the [Start] key will blink, and your copies will be made as soon as warm-up finishes.

**1 Make any adjustments to copy settings during the warm-up period.**

**2 Set your originals.**

**3 Press the [Start] key.**

The [Start] key indicator alternately flashes red and green.

**Note**

❒ To cancel Auto Start, press the [Clear/Stop] key.

## Original Tone

The key tone sounds and an error message is displayed when you leave your originals on the exposure glass for about two seconds after copying.

**Note**

❒ To cancel this function, see "11. Original Tone" in ⇒ P.80 *"1. General Features 3/4"*.

# Preset Reduce/Enlarge—Reducing and Enlarging Using Preset Ratios

You can select a preset ratio for copying.




**Note**

- ❒ You can select one of 6 present ratios (3 enlargement ratios, 3 reduction ratios).
- ❒ You can change the preset ratios to other ratios you frequently use. See "05. Set Ratio" in⇒ P.79 *"1. General Features 2/4"*.
- ❒ You can select a ratio regardless of the size of an original or copy paper. With some ratios, parts of the image might not be copied or margins will appear on copies.
- ❒ Copies can be reduced or enlarged as follows:

### ❖ Metric version

| Ratio (%) | Original → Copy paper size |
|---|---|
| 200 (enlarge area by 4)* | A5→A3 |
| 141 (enlarge area by 2)* | A4→A3, A5→A4 |
| 122* | F→A3, A4→B4 |
| 115 | B4→A3 |
| 93* | Create Margin. |
| 87 | A3→B4 |
| 82 | F→A4, B4→F |
| 71 (reduce area by 1/2)* | A3→A4, A4→A5 |
| 65 | A3→F |
| 50 (reduce area by 1/4)* | A3→A5, F→A5 |

* Default

### ❖ Inch version

| Ratio(%) | Original → Copy paper size |
|---|---|
| 200 (enlarge area by 4) | $5^1/_2$" × $8^1/_2$"→11" × 17" |
| 155 (enlarge area by 2)* | $5^1/_2$" × $8^1/_2$"→$8^1/_2$" × 14" |
| 129* | $8^1/_2$" × 11"→11" × 17" |
| 121* | $8^1/_2$" × 14"→11" × 17" |
| 93* | Create Margin |
| 85 | F→$8^1/_2$" × 11" |
| 78* | $8^1/_2$" × 14"→$8^1/_2$" × 11" |
| 74 | 11" × 14"→$8^1/_2$" × 11" |
| 65* | 11" × 17"→$8^1/_2$" × 11" |
| 50 (reduce area by 1/4) | 11" × 17"→$5^1/_2$" × $8^1/_2$" |

* Default

**1** **Press the [Enlarge] or [Reduce] key to select a ratio.**




**Note**

❒ Another preset ratio is displayed every time you press the key.

**2** **Set your originals, then press the [Start] key.**

# Zoom—Reducing and Enlarging in 1% Steps

You can change the reproduction ratio in 1% steps.




**Note**

- You can specify the reproduction ratio within between 50% and 200%.
- You can select a ratio regardless of the size of an original or copy paper. With some ratios, parts of the image might not be copied or margins will appear on copies.
- You can select a preset ratio which is near the desired ratio, then press the **[Zoom]** key and adjust the ratio with the **[+]** or **[−]** key.

**1** **Press the [Zoom] key.**




**2** **Enter the ratio.**

### When using the [+] or [−] key

**❶ Enter the desired reproduction ratios with the [−] or [+] key.**




**Note**

- To change the ratio in 1% steps, just press the **[+]** or **[−]** key. To change the ratio in 10% steps, press and hold down the **[+]** or **[−]** key.

### When using the [Number] keys

**❶ Enter the desired ratio with the [Number] keys.**

**Note**

- To change the ratio entered, press the **[Clear/Stop]** key and enter the new ratio.

**❷ Press the [OK] key.**

**3** **Set your originals, then press the [Start] key.**

# Combine—Combining Originals into One Copy

You can make 1 sheet of copies from 2 or more one sided originals.

2

### ❖ 2 pages→1-sheet

This mode makes two facing pages on one-sided copy.




### ❖ 4 pages→1-sheet

4 one-sided pages are copied onto 1 one-sided sheet.




### ❖ 8 pages→1-sheet

8 one-sided paper are copied onto 1 one-sided sheet.




### Limitation

- ❒ You cannot use the bypass tray with this function.
- ❒ The machine cannot copy originals different in size and direction.

### Note

- ❒ The number of originals copied (combined) can be 2, 4 or 8.
- ❒ In this mode, the machine selects the reproduction ratio automatically. This reproduction ratio depends on the copy paper sizes and the number of originals.
- ❒ The machine uses ratios within the range of 50 to 200%.
- ❒ If the calculated ratio is under the minimum ratio, it is corrected within the range of the ratio automatically. However, with some ratios, parts of the image might not be copied or blank margins appear on copies.
- ❒ When the number of originals placed is less than the number specified for combining, the last page(s) will be copied blank as shown in the illustration. See "1. Comb. Auto Eject" in⇒ P.77 *"Input/Output"*.




- ❒ Even if the direction of originals is different from that of the copy paper, the machine will automatically rotate the image by 90° to make copies properly.

❒ Direction of the originals and arrangement of combined images.

❖ **Portait ( ) originals**




GCSHUY1E

❖ **Landscape ( ) originals**




GCSHUY2E

❒ Separation line between originals cannot be printed.

**1** **Press the [Combine/Series Copies] key.**




THYS100E

**2** **Press the [Combine] key.**




THYS670E

**3** **Select the desired combine modes with the ◁▷ keys. Then, press the [OK] key.**




THYS860E

**4** **Press the [Exit] key.**




THYS620E

**5** **Press the ◁▷ keys to select the copy paper.**

## When setting a stack of originals in the document feeder

❶ **Set your originals, then press the [Start] key.**

**Note**

❒ The last page should be on the bottom.

## When setting an original on the exposure glass or in the document feeder

❶ **Set the original, then press the [Start] key.**

**Note**

❒ Start with the first page to be copied.

❷ **Set the next original, then press the [Start] key.**

**Note**

❒ When you set an original in the document feeder, the second and subsequent originals can be fed automatically without pressing the [Start] key.

❸ **After all originals are scanned, press the [#] key.**

# Series Copies—Making Two-sheets Copies from Book Originals

You can make one-sided copies from two facing pages of bound (book) originals.

### ❖ Book → 2-sheets

You can make two-sheets copies from two facing pages of a bound original (book).




### Note

❒ Refer to the following table when you select original and copy paper sizes with 100% ratio:

#### ❖ Metric version

| Original | Copy paper |
|---|---|
| A3 | A4 × 2 sheets |
| B4 | B5 × 2 sheets |
| A4 | A5 × 2 sheets |

#### ❖ Inch version

| Original | Copy paper |
|---|---|
| 11" × 17" | $8^1/_2$" × 11" × 2 sheets |
| $8^1/_2$" × 11" | $5^1/_2$" × $8^1/_2$" × 2 sheets |

**1** Press the [Combine/Series Copies] key.




THYS100E

**2** Press the [Series] key.






THYS760E

**3** Press the [OK] key.






THYS620E

4 Press the [Exit] key.




5 Set your originals, then press the [Start] key.

# Combination Chart

The combination chart given below shows which modes can be used together. When you read the chart, please refer to the following table.

| | |
|---|---|
| ☆ | means that these modes can be used together. |
| → | means that these modes cannot be used together. The mode after you select will be the mode you're working in. |
| × | means that these modes cannot be used together. The mode before you select will be the mode you're working in. |



The following shows the combinations of functions.

| Mode before you Select | Mode after you Select: Setting Originals on the Exposure Glass | Setting Originals in the Document Feeder | Input the Original size | Auto Image Density | Lighter/Darker | Text | Text•Photo | Photo | Auto Paper Select | Auto Reduce/Enlarge | Sort | Copying from the Bypass Tray | Reduce/Enlarge | Zoom | Combine | Series Copies |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Setting Originals on the Exposure Glass | — | → | × | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ |
| Setting Originals in the Document Feeder | × | — | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ |
| Input the Original size | → | ☆ | — | ☆ | ☆ | ☆ | ☆ | ☆ | × | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ |
| Auto Image Density | ☆ | ☆ | ☆ | — | *1 | *3 | *3 | *3 | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ |
| Lighter/Darker | ☆ | ☆ | ☆ | → | — | *3 | *3 | *3 | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ |
| Text | ☆ | ☆ | ☆ | ☆ | ☆ | — | → | → | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ |
| Text•Photo | ☆ | ☆ | ☆ | ☆ | ☆ | → | — | → | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ |
| Photo | ☆ | ☆ | ☆ | ☆ | ☆ | → | → | — | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ |
| Auto Paper Select | ☆ | ☆ | × | ☆ | ☆ | ☆ | ☆ | ☆ | — | → | ☆ | → | ☆ | ☆ | → | → |
| Auto Reduce/Enlarge | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | × | — | ☆ | *2 | → | → | → | → |
| Sort | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | — | *2 | ☆ | ☆ | ☆ | ☆ |
| Copying from the Bypass Tray | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | → | *2 | *2 | — | ☆ | ☆ | *2 | *2 |
| Reduce/Enlarge | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | → | ☆ | ☆ | — | ☆ | → | ☆ |
| Zoom | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | → | ☆ | ☆ | ☆ | — | → | ☆ |
| Combine | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | × | ☆ | ☆ | *2 | ☆ | ☆ | — | → |
| Series Copies | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | × | × | ☆ | *2 | ☆ | ☆ | → | — |

*1 Combined auto and manual image density.
*2 "××× cannot be selected" is displayed.
*3 Depending on "02. ADS Priority".